

MW SERIES SIDE & REAR DISCHARGE MID-MOUNT MOWERS

for Farmall® Compact Tractors – Specifications



Models MW60S, MW72S, MW72R & MW84R

MODEL	MW60S*	MW72S*	MW72R*	MW84R*
TRACTOR COMPATIBILITY	Farmall 31 & Farmall 35	Farmall 31 & Farmall 35	Farmall 31 & Farmall 35	Farmall 40 & Farmall 45
Discharge	Side discharge	Side discharge	Rear Discharge	Rear discharge
Mulching design	NA	NA	Yes	Yes
Cutting Width	60 in. (152 cm)	72 in. (183 cm)	72 in. (183 cm)	84 in. (213 cm)
Cutting Height	1.5 to 4 in. (3.8 to 10.2 cm)	1.5 to 4 in. (3.8 to 10.2 cm)	1.5 to 4 in. (3.8 to 10.2 cm)	2 to 4 in. (5 to 10.2 cm)
Overall Width	76.5 in. (194 cm)	85.5 in. (217 cm)	74.4 in. (189 cm)	87.4 in. (222 cm)
Number of Blades	3	3	3	4
Blade Type	High Lift	Standard	Standard	Gator Mulcher™ Blades
Blade Length/Width	20.4 x 2.5 in. (51.8 x 6.4 cm)	24.5 x 3 in. (51.8 x 7.6 cm)	24.5 x 3 in. (62.2 x 7.6 cm)	22.8 x 3 in. (58.6 x 7.3 cm)
Blade Tip Speed	15,306 fpm (4665 mpm)	15,616 fpm (4760 mpm)	15,616 fpm (4760 mpm)	15,616 fpm (4760 mpm)
Drive	Mid-PTO	Mid-PTO	Mid-PTO	Mid-PTO
Gauge Wheels	6 x 2.5 in. (15.2 x 6.4 cm)	6 x 2.5 in. (15.2 x 6.4 cm)	6 x 2.5 in. (15.2 x 6.4 cm)	6 x 2.5 in. (15.2 x 6.4 cm)
Deck Spring Suspension	Standard	Standard	Standard	Standard
Compatibility with Loader	Yes	Yes	Yes	Yes
Tire Compatibility:				
Agricultural (R1)	No	No	Yes	Yes
Industrial (R4)	Yes	Yes	Yes	Yes
Turf (R3)	Yes	Yes	Yes	Yes
Galaxy Turf	Yes	Yes	Yes	Yes

* Available for tractor models equipped with mid PTO.

NOTE: All specifications are stated in accordance with SAE Standards or Recommended Practices, where applicable.

© 2008 CNH America LLC. All rights reserved. www.caseih.com/na

CNH America LLC reserves the right to make improvements in design and changes in specifications at any time without notice and without incurring any obligation to install them on units previously sold. Specifications, descriptions and illustrative material herein are as accurate as known at time of publication, but are subject to change without notice.



SAFETY NEVER HURTS!™ Always read the Operator's Manual before operating any equipment. Inspect equipment before using it, and be sure it is operating properly. Follow the product safety signs, and use any safety features provided.