

3200/3400 SERIES CORN HEAD Specifications



Models 3206, 3208, 3212, 3406, 3408 & 3412

MODEL	3206/3406	3208/3408	3212/3412
GENERAL			
Number of rows	6	8	12
Row spacing — in. (mm)	30, 36, 38 (762, 914, 965)	22, 30, 36, 38 (559, 762, 914, 965)	20, 22, 30 (508, 559, 762)
OVERALL DIMENSIONS			
Width (Max. row spacing)			
20 in. (508 mm)	N/A	N/A	20 ft. 10 in. (6350 mm)
22 in. (559 mm)	N/A	15 ft. 6 in. (4724 mm)	22 ft. 10 in. (6960 mm)
30 in. (762 mm)	15 ft. 10 in. (4824 mm)	20 ft. 10 in. (6356 mm)	30 ft. 10 in. (9404 mm)
36 in. (914 mm)	18 ft. 6 in. (5645 mm)	24 ft. 8 in. (7511 mm)	N/A
38 in. (965 mm)	19 ft. 2 in. (5848 mm)	25 ft. 6 in. (7778 mm)	N/A
Height (level ground)	3 ft. 11 in. (1197 mm)	3 ft. 11 in. (1197 mm)	3 ft. 11 in. (1197 mm)
Length with dividers	10 ft. 4 in. (3158 mm)	10 ft. 4 in. (3158 mm)	10 ft. 4 in. (3158 mm)
Length without dividers	7 ft. 4 in. (2234 mm)	7 ft. 4 in. (2234 mm)	7 ft. 4 in. (2234 mm)
WEIGHT: APPROX. – LBS. (KG)			
20 in. (508 mm)	N/A	N/A	7,165 (3257)
22 in. (559 mm)	N/A	4,950 (2250)	7,670 (3486)
30 in. (762 mm)	4,165 (1893)	5,780 (2627)	8,510 (3868)
36 in. (914 mm)	4,740 (2155)	6,315 (2870)	N/A
38 in. (965 mm)	4,740 (2155)	6,315 (2870)	N/A
Point-to-point knife-type stalk rolls	Standard	Standard	Standard
Number of knives per roll	4 - Single edge	4 - Single edge	4 - Single edge
Weed knives – front and rear	Adjustable	Adjustable	Adjustable
Row unit drive	Enclosed in gearbox	Enclosed in gearbox	Enclosed in gearbox
Head speed	521 RPM	521 RPM	521 RPM
Speed ranges	2 – Direct/overdrive	2 – Direct/overdrive	2 – Direct/overdrive
Stripper plates	Hydraulic adjustable	Hydraulic adjustable	Hydraulic adjustable
Automatic front height control	Optional/pre-wired	Optional/pre-wired	Optional/pre-wired

NOTE: All specifications are stated in accordance with SAE Standards or Recommended Practices, where applicable.

© 2009 CNH America LLC. All rights reserved. www.caseih.com/na

CNH America LLC reserves the right to make improvements in design and changes in specifications at any time without notice and without incurring any obligation to install them on units previously sold. Specifications, descriptions and illustrative material herein are as accurate as known at time of publication, but are subject to change without notice.

 **SAFETY NEVER HURTS!™** Always read the Operator's Manual before operating any equipment. Inspect equipment before using it, and be sure it is operating properly. Follow the product safety signs, and use any safety features provided.